


Patient Instructions

Urine Collection using the Vacutest™ System (*Kima*)

Important- Do not remove the lid from the test tube at any point of the procedure.

1




Wash hands and genital area.

2



Urine should be collected 'midstream' into the collection container, up to the **Fill line**.

3




Screw the lid back on to container cup.

4



Peel back protective sticker.

5



- Insert capped test tube firmly into the exposed opening of the container.
- Urine will flow freely into the attached tube.
- When full, remove the tube from the container.

6

Once the test tube has been filled, please dispose the remaining urine into the toilet.

8



Wash and dry your hands.

7

Please return the test tube and empty collection cup to your GP surgery or clinic in the specimen bag provided.

Document Name	Patient Instructions: Urine Collection using the Vacutest™ System (<i>Kima</i>)		
Q Pulse ID	BCHEM-GEN-SOP19	Page	1 of 1
Version	2	Date of Issue	July 2017